


EXPLODED DIAGRAM AND PARTS LIST

T-Anchor Machine



Part No.	Description	Qty.	Part No.	Description	Qty.	Part No.	Description	Qty.
1	Housing	1	26	Hex ring	1	51	Nut	2
2	Trigger	1	27	Bushing	1	52	Screw	2
3	trigger pin	1	28	Fix ring	1	53	Shaft	1
4	O-ring	1	29	Collet	1	54	Nut	1
5	O-ring	1	30	Collet jacket	1	55	Set plate	1
6	valve stem	1	31	Diamond hole drill bit	1	56	Soft liner	1
7	Spring	1	32	Handle hold base	1	57	Left support base	1
8	O-ring	1	33	Handle hold collar	1	58	Water valve base	1
9	Screw nut	1	34	Handle connector	1	59	Water diverter	1
10	Exhaust deflector	1	35	Safety base	1	60	Water valve	1
11	Air inlet	1	36	Spring	1	61	O-ring	2
12	Bearing	1	37	Safety bolt	1	62	Cushion	1
13	Rear plate	1	38	E-clip	1	63	Screw plug	1
14	Steel ball	1	39	Screw	1	64	Water regulating knob	1
15	Rotor	1	40	Screw	2	65	Screw	1
16	Roter blade	4	41	Handle	1	66	Water valve support	1
17	Cylinder	1	42	Clip	1	67	Screw	2
18	Bushing	1	43	Right support base	1	68	Gasket	2
19	Front plate	1	44	Short column	1	69	Ball valve	1
20	Steel ball	1	45	Bottom base	1	70	Valve cover	1
21	Bolt	1	46	Connector	2	71	Water inlet	1
22	Bearing	1	47	Set handle	1	72	Long column	2
23	Collet seat	1	48	Rivet	3	73	Spring	1
24	Set ring	1	49	Screw	8			
25	Oil seal	1	50	Screw	4			